



1. Area where a temporary bund will be build with sandbags. The wall of the bund will be about 4 sandbags high.
2. Area where vacuum truck will be parked when removing hydrocarbons from the bund.