


SYMBOLS LEGEND:

PRESSURE REDUCING VALVE
AUTOMATIC CONTROL VALVE

GENERIC ISOLATION VALVE

 \bowtie



REMOVE FLOAT VALVE AND MODIFY INLET PIPE END (RAISE ABOVE PROPOSED WATER LEVEL). INSTALL PILOTED FLOAT VALVE.