

1 MBRUSH 068

2 * Overhauling MBRUSH 068 (typically a 2-stroke or 4-stroke petrol brush cutter)

1. Engine & Inspection

- **Cylinder and Piston:**
 - Remove the engine cover and cylinder block.
 - Check for deep scores.
 - replace the piston, rings, and
 - check, repair or replace cylinder block.
- **Gaskets and Seals:**
 - Clean the mating surfaces and install new gasket kit.
- **Spark Plug:**
 - Replace the spark plug and ensure the gap is set correctly

2. Fuel System Overhaul

- **Carburetor:**
 - Remove the carburetor
 - Replace the internal diaphragms, gaskets, and the primer bulb.
- **Fuel Lines and Filters:**
 - Replace fuel lines and the in-tank fuel filter.
- **Air Filter:** Fit new air filter.

3. Drive Shaft & Gearbox Servicing

- **Drive Shaft**
 - Replace shaft.
 - Check, repair or replace bearings
- **Cutting Head Gearbox:**
 - Check, repair or replace

4. Cutting Mechanism

- **Blade/Trimmer Head:**
 - Inspect or replace the cutting attachment.

5. Reassembly & Tuning

- Reassemble all components and start the machine
- Check, repair or replace starting mechanism
- Service and tune the machine
- Provide warranty

2 STIHL C-EM

2*Overhauling a STIHL FS461 C-EM professional brush cutter

1. Drivetrain and Cutting Head Overhaul

The cutting head and drive shaft take the brunt of the wear and tear during heavy brush clearing.

- **Trimmer Head/Blade:**
 - Check, repair or replace
- **Gear Housing (Angle Drive):**
 - T Check, repair or replace
- **Drive Shaft:**
 - Check, repair or replace

2. Engine & Inspection

- **Cylinder and Piston:**
 - Remove the engine cover and cylinder block.
 - Check for deep scores.
 - replace the piston, rings, and
 - check, repair or replace cylinder block.
- **Gaskets and Seals:**
 - Clean the mating surfaces and install new gasket kit.
- **Spark Plug:**
 - Replace the spark plug and ensure the gap is set correctly

3. Fuel System Overhaul

- **Carburetor:**
 - Remove the carburetor
 - Replace the internal diaphragms, gaskets, and the primer bulb.
- **Fuel Lines and Filters:**
 - Replace fuel lines and the in-tank fuel filter.
- **Air Filter:** Fit new air filter.

4. Drive Shaft & Gearbox Servicing

- **Drive Shaft**
 - Replace shaft.
 - Check, repair or replace bearings
- **Cutting Head Gearbox:**
 - Check, repair or replace

5. Cutting Mechanism

- **Blade/Trimmer Head:**
 - Inspect or replace the cutting attachment.

6. Reassembly & Tuning

- Reassemble all components and start the machine
- Check, repair or replace starting mechanism
- Service and tune the machine
- Provide warranty

3 RYOBI Blower Backpack

2*Repair and Service RYOBI Blower Back Pack

1. Supplier to collect machine
2. Check, strip and repair
3. Do a full service on the machine
 - Replace spark plug
 - Replace oil
 - Check and repair starting mechanism
4. Start and test the machine













RYOBI RSV-5200
BACKPACK BLOWER
2 stroke engine x 52cc/1.5 kW
Fuel pressure and oil mix ratio 40:1
Max speed: 2800rpm
Fuel tank capacity: 880ml
Air velocity: 80m/s
Air volume: 4120m³/h
Net



