



| LEGEND    |  |
|-----------|--|
| BP        | Busbar Earthing Point                              |
| SGF       | Terminal in Switchgear, Front Relay Panel          |
| ES        | Terminal in Switchgear, Rear Secondary Cable Box   |
| ES        | Earth Switch                                       |
| CB        | Circuit Breaker                                    |
| DS        | Disconnecting Switch                               |
| B81       | Busbar 1   |
| B82       | Busbar 2   |
| FE        | Feeder Switch                                      |
| TC3       | Trp Circuit Supervision                            |
| P8        | Push Button  |
| PIB       | Pilot Board  |
| SC6A      | SC6A Gateway                                       |
| J1        | DC +ve Busbar                                      |
| J2        | DC -ve Busbar                                      |
| RT1 & RT2 | Relay Fail Alarms                                  |
| B51       | Bus Section 1                                      |
| B52       | Bus Section 2                                      |
| +         | Contact which is 'Closed' when Contact is 'Closed' |
| -         | Contact which is 'Closed' when Contact is 'Open'   |
| ≡         | Fuse   |
| □         | LYK  |
| ⏏         | Control Switch                                     |
| ⏏         | Push Button  |
| ⏏         | Relay Digital Input                                |
| ⏏         | Relay Analog Input                                 |
| ⏏         | Normally Open Contact                              |
| ⏏         | Normally Closed Contact                            |
| ⏏         | Current Transformer                                |