

clarify the follow up questions:

1. What is the length of the overhead and underground cables? The length of both overhead and underground cables are measured in kilometres. Bidders may quote the security measures to be applied, per kilometre.
2. Which lines are under ground, and which is overhead? The lines are indicated on the MAP. See also above response for better quoting purposes.
3. When can we visit your control room? It was explained at the clarification meeting that individual appointment may be made with Middelburg Control room at these numbers 0727518149 or 013 6934296, ask for NOMPI or Aletta.
4. Where / which sites do you require breathalysers? The two office sites, namely Delmas CNC and 8 Smuts Avenue.