

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
Air Heater															
0	General														
0.01	Site establishment for OP		X												
0.02	Site establishment for IN			X											
0.03	Site establishment for IR				X										
0.04	Site establishment for GO					X									
0.05	Site de-establishment for OP		X												
0.06	Site de-establishment for IN			X											
0.07	Site de-establishment for IR				X										
0.08	Site de-establishment for GO					X									
0.09	Open all inspection and access doors (excluding main sliding door)		X	X	X	X									
0.10	Close hood doors, bearing compartment door and inspection doors including fitting of new packing		X	X	X	X									
0.11	Open main sliding door					X									
0.12	Close main sliding door including fitting of new packing					X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
1	Air Heater Inspection OP														
1.01	Visually inspect the air heater for any damage and erosion		X												
2	Air Heater Inspection IN														
2.01	a) Visually inspect stator face damage b) Visually inspect seal frame, articulation joints and wear seals hot end and cold end c) Inspect stainless steel expansion joints hot end and cold end d) Inspect hood and hood doors hot end and cold end e) Visually inspect pins, springs and spring pins hot end and cold end f) Visually inspect drag links, center drive posts and nudging pins hot end and cold end g) Visually inspect thermal compensators (where fitted) h) Inspect collar seals i) Visually inspect pin rack and measure pinion wear j) Inspect motor drive and gearbox in situ k) Visually inspect sootblower system, cross bellows, center bellows, indexing paddle system, steam piping and erosion protection l) Inspect fire fighting system where fitted m) Inspect element packs visually in fitted position n) Visually inspect lubrication oil tunnel o) Inspect lubrication oil system p) Visually inspect transition ducting hot end and cold end q) Inspect all stay rods and erosion protection r) Inspect pack supports s) Inspect erosion protection t) Visually inspect the bearing compartment u) Inspect pinion shaft plumber block bearings			X											

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
3	Air Heater Inspection IR														
3.01	a) Inspect stator face damage, levels, shaft and hood alignment b) Inspect seal frame, articulation joints and wear seals hot end and cold end c) Inspect all stainless steel expansion joints d) Inspect hood and hood doors hot end and cold end e) Inspect pins, springs and spring pin settings hot end and cold end f) Inspect drag links, center drive posts and nudging pins hot end and cold end g) Inspect thermal compensators (where fitted) h) Inspect collar seals by opening covers top and bottom including collar seal alignment and runouts i) Inspect pin rack and pinion j) Inspect motor drive and gearbox in situ k) Inspect sootblower system, cross bellows, center bellows with TIR, indexing paddle system and steam piping l) Inspect fire fighting system where fitted m) Inspect element packs visually in fitted position n) Inspect lubrication oil tunnel o) Inspect lubrication oil system p) Inspect transition ducting hot and cold end with spot thickness testing and visual q) Inspect all stay rods r) Inspect pack supports s) Inspect all erosion protection and report on consolidated list with erosion protection fitted and wear status t) Visually inspect the bearing compartment u) Visually inspect pinion shaft plumber block bearings			X											

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
4	Air Heater Inspection GO														
4.01	a) Inspect stator face damage, levels, shaft and hood alignment b) Inspect seal frame, articulation joints and wear seals hot end and cold end c) Inspect all stainless steel expansion joints d) Inspect hood and hood doors hot end and cold end e) Inspect pins, springs and spring pin settings hot end and cold end f) Inspect drag links, center drive posts and nudging pins hot end and cold end g) Inspect thermal compensators (where fitted) h) Inspect collar seals by opening covers top and bottom including collar seal alignment and runouts i) Inspect pin rack and pinion j) Inspect motor drive and gearbox in situ k) Inspect sootblower system, cross bellows, center bellows with TIR, indexing paddle system and steam piping l) Inspect fire fighting system where fitted m) Inspect element packs visually in fitted position n) Inspect lubrication oil tunnel o) Inspect lubrication oil system p) Inspect transition ducting hot and cold end with spot thickness testing and visual q) Inspect all stay rods r) Inspect pack supports s) Inspect all erosion protection and report on consolidated list with erosion protection fitted and wear status t) Visually inspect the bearing compartment u) Visually inspect pinion shaft plumber block bearings					X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
5	Stator - Single Flow														
5.01	Inspect complete stator after element packs have been removed for damage and wear including the lub tunnel casing. Submit detailed report					X									
5.02	Remove all stator element pack supports on the cold end					X									
5.03	Refit all stator element pack supports on the cold end					X									
5.04	Remove 50 off complete basket element pack supports				X										
5.05	Refit 50 off complete basket element pack supports				X										
5.06	Remove 10 off complete basket element pack supports			X											
5.07	Refit 10 off complete basket element pack supports			X											
5.08	Carry out stator radial and divisional plate window repairs by cutting out and rewelding 1.0m in total of 6mm thick plate when packs are removed														
5.09	Carry out stator radial and divisional plate window repairs by cutting out and rewelding 5.0m in total of 6mm thick plate when packs are removed			X											
5.10	Carry out stator radial and divisional plate window repairs by cutting out and rewelding 10.0m in total of 6mm thick plate when packs are removed														
5.11	Carry out stator radial and divisional plate window repairs by cutting out and rewelding 20.0m in total of 6mm thick plate when packs are removed				X										
5.12	Carry out stator radial and divisional plate window repairs by cutting out and rewelding 50.0m in total of 6mm thick plate when packs are removed					X									
5.13	Carry out stator radial and divisional plate window repairs by cutting out and rewelding 1.0m in total of 10mm thick plate when packs are removed														
5.14	Carry out stator radial and divisional plate window repairs by cutting out and rewelding 5.0m in total of 10mm thick plate when packs are removed			X											
5.15	Carry out stator radial and divisional plate window repairs by cutting out and rewelding 10.0m in total of 10mm thick plate when packs are removed				X										
5.16	Carry out stator radial and divisional plate window repairs by cutting out and rewelding 20.0m in total of 10mm thick plate when packs are removed					X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
5.17	Remove all radial plate U-Channel/flat bar strips hot end					X									
5.18	Refit all radial plate flat bar strips hot end					X									
5.19	Remove 24 off radial plate U-Channel/flat bar strips hot end				X										
5.20	Refit 24 off radial plate flat bar strips hot end				X										
5.21	Remove 12 off radial plate U-Channel/flat bar strips hot end			X											
5.22	Refit 12 off radial plate flat bar strips hot end			X											
5.23	Remove all radial plate U-Channel/flat bar strips cold end					X									
5.24	Refit all radial plate flat bar strips cold end					X									
5.25	Remove 24 off radial plate U-Channel/flat bar strips cold end														
5.26	Refit 24 off radial plate flat bar strips cold end														
5.27	Remove 12 off radial plate U-Channel/flat bar strips cold end														
5.28	Refit 12 off radial plate flat bar strips cold end														
5.29	Fit complete new stator periphery flange hot end to correct procedure (Only to be done in conjunction with radial plate flat bar to reinstate complete stator surface. Hub plate also needs to be considered)														
5.30	Fit complete new stator periphery flange cold end to correct procedure (Only to be done in conjunction with radial plate flat bar to reinstate complete stator surface. Hub plate also needs to be considered)														
5.31	Fit complete new stator hub plate on the hot end to correct procedure (Only to be done in conjunction with above radial plate flat bar replacement and stator periphery flange to reinstate complete stator surface)														
5.32	Fit complete new stator hub plate on the cold end to correct procedure (Only to be done in conjunction with above radial plate flat bar replacement and stator periphery flange to reinstate complete stator surface)														
5.33	Remove complete lub tunnel including pipe removal					X									
5.34	Refit complete lub tunnel including pipe re-installation					X									
6	Element Packs														
6.01	Remove 3 selected element packs top and intermediate/cold layer			X	X	X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
6.02	Split open packs, remove one plate pair re-assemble pack			X	X	X									
6.03	Refit 3 removed packs			X	X	X									
6.04	Mark plate pair and send for mass analysis			X	X	X									
6.05	Analyse plate mass loss and submit report on findings and record in database			X	X	X									
7	Seal Frames - Single Flow														
7.01	Remove complete seal frame hot end					X									
7.02	Refit complete seal frame hot end					X									
7.03	Remove complete seal frame cold end														
7.04	Refit complete seal frame cold end														
7.05	Remove hub section seal frame hot end														
7.06	Refit hub section seal frame hot end														
7.07	Remove hub section seal frame cold end														
7.08	Refit hub section seal frame cold end														
7.09	Remove one leading edge section of seal frame hot end			X											
7.10	Refit one leading edge section of seal frame hot end			X											
7.11	Remove two leading edge section of seal frame hot end				X										
7.12	Refit two leading edge section of seal frame hot end				X										
7.13	Remove one leading edge section of seal frame cold end														
7.14	Refit one leading edge section of seal frame cold end														
7.15	Remove one periphery section of seal frame hot end			X											
7.16	Refit one periphery section of seal frame hot end			X											
7.17	Remove two periphery section of seal frame hot end				X										
7.18	Refit two periphery section of seal frame hot end				X										
7.19	Remove one periphery section of seal frame cold end														
7.20	Refit one periphery section of seal frame cold end														
8	Stainless Steel Expansion Joints - Single Flow														
8.01	Remove complete set of stainless steel expansion joints hot end					X									
8.02	Refit complete set of stainless steel expansion joints hot end					X									
8.03	Remove complete set of stainless steel expansion joints cold end					X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
8.04	Refit complete set of stainless steel expansion joints cold end					X									
8.05	Remove hubs section stainless steel expansion joints hot end														
8.06	Refit hub section stainless steel expansion joints hot end														
8.07	Remove hubs section stainless steel expansion joints cold end														
8.08	Refit hub section stainless steel expansion joints cold end														
8.09	Remove one complete leading edge or trailing edge section stainless steel expansion joints hot end			X	X										
8.10	Refit one complete leading edge or trailing edge section stainless steel expansion joints hot end			X	X										
8.11	Remove one complete leading edge or trailing edge section stainless steel expansion joints cold end			X											
8.12	Refit one complete leading edge or trailing edge section stainless steel expansion joints cold end			X											
8.13	Remove one periphery section of stainless steel expansion joints hot end			X											
8.14	Refit one periphery section of stainless steel expansion joints hot end			X											
8.15	Remove one periphery section of stainless steel expansion joints cold end														
8.16	Refit one periphery section of stainless steel expansion joints cold end														
8.17	Remove one section of stainless steel expansion joint hot end														
8.18	Refit one section of stainless steel expansion joint hot end														
8.19	Remove one section of stainless steel expansion joint cold end														
8.20	Refit one section of stainless steel expansion joint cold end														
8.21	Remove four sections of stainless steel expansion joint hot end			X	X										
8.22	Refit four sections of stainless steel expansion joint hot end			X	X										
8.23	Remove four sections of stainless steel expansion joint cold end			X	X										
8.24	Refit four sections of stainless steel expansion joint cold end			X	X										

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
9	Cast Iron Wear Seals														
9.01	Remove complete set of cast iron wear seals hot end					X									
9.02	Refit complete set of cast iron wear seals hot end					X									
9.03	Remove complete set of cast iron wear seals cold end					X									
9.04	Refit complete set of cast iron wear seals cold end					X									
9.05	Remove hub section cast iron wear seals hot end														
9.06	Refit hub section cast iron wear seals hot end														
9.07	Remove hub section cast iron wear seals cold end														
9.08	Refit hub section cast iron wear seals cold end														
9.09	Remove one complete leading edge section cast iron wear seals hot end			X	X										
9.10	Refit one complete leading edge section cast iron wear seals hot end			X	X										
9.11	Remove one complete leading edge section cast iron wear seals cold end				X										
9.12	Refit one complete leading edge section cast iron wear seals cold end				X										
9.13	Remove one complete periphery section cast iron wear seals including both corner seals and one radial arm seal each side hot end			X	X										
9.14	Refit one complete periphery section cast iron wear seals including both corner seals and one radial arm seal each side and ensure blend in is correct hot end			X	X										
9.15	Remove one complete periphery section cast iron wear seals including both corner seals and one radial arm seal each side cold end														
9.16	Refit one complete periphery section cast iron wear seals including both corner seals and one radial arm seal each side and blend in is correct cold end														
9.17	Remove one cast iron wear seal hot end														
9.18	Refit one cast iron wear seal hot end														
9.19	Remove one cast iron wear seal cold end														
9.20	Refit one cast iron wear seal cold end														
9.21	Remove five cast iron wear seals hot end			X	X										
9.22	Refit five cast iron wear seals hot end			X	X										
9.23	Remove five cast iron wear seals cold end			X	X										
9.24	Refit five cast iron wear seals cold end			X	X										
10	Spring Pins and Springs														
10.01	Remove all the springs and pins hot end					X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
10.02	Refit all the springs and pins hot end					X									
10.03	Remove hub springs and spring pins hot end														
10.04	Refit hub springs and spring pins hot end														
10.05	Remove one secondary hood periphery side corner spring and pin hot end														
10.06	Refit one secondary hood periphery side corner spring and pin hot end														
10.07	Remove one radial arm leading or trailing edge section spring and pin hot end														
10.08	Refit one radial arm leading or trailing edge section spring and pin hot end														
10.09	Remove all the springs and pins cold end					X									
10.10	Refit all the springs and pins cold end					X									
10.11	Remove hub springs and spring pins cold end														
10.12	Refit hub springs and spring pins cold end														
10.13	Remove one secondary hood periphery side corner spring and pin cold end														
10.14	Refit one secondary hood periphery side corner spring and pin cold end														
10.15	Remove one radial arm leading or trailing edge section spring and pin cold end														
10.16	Refit one radial arm leading or trailing edge section spring and pin cold end														
10.17	Remove one complete spring pin assembly hot end														
10.18	Re-align and refit one complete spring pin assembly hot end														
10.19	Remove one complete spring pin assembly cold end														
10.20	Re-align and refit one complete spring pin assembly cold end														
10.21	Carry out complete air heater seal setting hot end				X	X									
10.22	Carry out complete air heater seal setting cold end				X	X									
10.23	Carry out trim adjustment of air heater seal setting nut gaps and shoe gaps complete hot end				X										
10.24	Carry out trim adjustment of air heater seal setting nut gaps and shoe gaps complete cold end				X										
10.25	Carry out trim adjustment of air heater seal setting nut gaps and shoe gaps periphery springs only hot end			X											
10.26	Carry out trim adjustment of air heater seal setting nut gaps and shoe gaps periphery springs only cold end			X											
11	Articulation Joints														

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
11.01	Remove one bolt in type articulation joint hot end														
11.02	Refit one bolt in type articulation joint complete with protection covers hot end														
11.03	Remove four bolt in type articulation joint hot end			X	X										
11.04	Refit four bolt in type articulation joint complete with protection covers hot end			X	X										
11.05	Remove one bolt in type articulation joint cold end														
11.06	Refit one bolt in type articulation joint complete with protection covers cold end														
11.07	Remove four bolt in type articulation joint cold end														
11.08	Refit four bolt in type articulation joint complete with protection covers cold end														
11.09	Remove erosion protection on one articulation joint hot end														
11.10	Refit new erosion protection on one articulation joint hot end														
11.11	Remove erosion protection on four articulation joints hot end			X	X	X									
11.12	Refit new erosion protection on four articulation joints hot end			X	X	X									
11.13	Remove erosion protection on one articulation joint cold end														
11.14	Refit new erosion protection on one articulation joint cold end														
11.15	Remove erosion protection on four articulation joints cold end														
11.16	Refit new erosion protection on four articulation joints cold end														
11.17	Remove one weld in type articulation joint hot end														
11.18	Refit one weld in type articulation joint complete with protection covers hot end														
11.19	Remove four weld in type articulation joint hot end														
11.20	Refit four weld in type articulation joint complete with protection covers hot end														
11.21	Remove one weld in type articulation joint cold end														
11.22	Refit one weld in type articulation joint complete with protection covers cold end														
11.23	Remove four weld in type articulation joint cold end														
11.24	Refit four weld in type articulation joint complete with protection covers cold end														
12	Center Post, Drag Links and Nudging pins														
12.01	Service hot end center posts			X	X	X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
12.02	Remove one drag link hot end														
12.03	Refit one drag link hot end														
12.04	Service drag links hot end					X									
12.05	Remove one nudging pin hot end														
12.06	Reset one nudging pin hot end														
12.07	Refit one nudging pin hot end														
12.08	Remove two nudging pins hot end														
12.09	Refit two nudging pins hot end														
12.10	Reset/Reposition one nudging pin hot end														
12.11	Service cold end center posts			X	X	X									
12.12	Remove one drag link cold end														
12.13	Refit one drag link cold end														
12.14	Service drag links cold end					X									
12.15	Remove one nudging pin cold end														
12.16	Reset one nudging pin cold end														
12.17	Refit one nudging pin cold end														
12.18	Remove two nudging pins cold end														
12.19	Refit two nudging pins cold end														
12.20	Reset/Reposition one nudging pin cold end														
13	Hoods - Single Flow														
13.01	Refurbish hood doors by carrying out minor repairs to hood doors, hinges and locking device			X	X	X									
13.02	Remove complete hood door														
13.03	Refit complete new hood door														
13.04	Carry out thickness testing on both hot end hoods					X									
13.05	Carry out thickness testing on both cold end hoods					X									
13.06	Carry out minor welding repair on hood turning vanes			X											
13.07	Carry out minor welding repair on hood stiffener pipes			X											
13.08	Remove 1 complete hood turning vane														
13.09	Refit 1 complete hood turning vane														
13.10	Remove 4 off complete hood turning vanes														
13.11	Refit 4 off complete hood turning vanes														
13.12	Remove 1 meter of hood pipe stiffeners														
13.13	Refit 1 meter of hood pipe stiffeners														
13.14	Remove 5 meters of hood pipe stiffeners														
13.15	Refit 5 meters of hood pipe stiffeners														
13.16	Remove 10 meters of hood pipe stiffeners														
13.17	Refit 10 meters of hood pipe stiffeners														
13.18	Carry out window repairs of 1.0m in total of 6mm thick hood plate by cutting out and re-welding with new material.			X											

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
13.19	Carry out window repairs of 5.0m in total of 6mm thick hood plate by cutting out and re-welding with new material				X										
13.20	Weld repair hood leading edge frame surface 1.0m			X											
13.21	Weld repair hood leading edge frame surface 4.0m				X										
13.22	Weld repair hood periphery frame surface 1.0m			X											
13.23	Weld repair hood periphery frame surface 4.0m				X										
14	Thermal Compensators														
14.01	Remove one thermal compensator rod			X											
14.02	Refit one thermal compensator rod			X											
14.03	Remove 4 thermal compensator rods				X	X									
14.04	Refit 4 thermal compensator rods				X	X									
14.05	Remove all thermal compensator rods														
14.06	Refit all thermal compensator rods														
14.07	Remove one thermal compensator erosion protection plates			X											
14.08	Refit one thermal compensator erosion protection plates			X											
14.09	Remove 4 thermal compensator erosion protection plates				X										
14.10	Refit 4 thermal compensator erosion protection plates				X										
14.11	Remove all thermal compensator erosion protection plates					X									
14.12	Refit all thermal compensator erosion protection plates					X									
14.13	Repair erosion damage on one thermal compensator box			X											
14.14	Repair erosion damage on 4 thermal compensator boxes				X										
14.15	Repair erosion damage on all thermal compensator boxes					X									
14.16	Carry out minor repairs to one thermal compensator bell crank system			X											
14.17	Carry out minor repairs to 4 thermal compensator bell crank systems				X										
14.18	Carry out minor repairs to all thermal compensator bell crank systems					X									
15	Collar Seals - Angular Tension Boxes														
15.01	Open all collar seal spring boxes hot end, inspect and report			X	X	X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
15.02	Refit new springs and stop washers on spring boxes hot end including checking for correct tensioning					X									
15.03	Close up spring boxes hot end			X	X	X									
15.04	Remove erosion protection on 1 spring box hot end														
15.05	Refit new erosion protection on 1 spring box hot end														
15.06	Remove erosion protection on 2 spring boxes hot end			X	X										
15.07	Refit new erosion protection on 2 spring boxes hot end			X	X										
15.08	Remove erosion protection on all spring boxes hot end					X									
15.09	Refit new erosion protection on all spring boxes hot end					X									
15.10	Remove all collar seal cast iron wear seals hot end					X									
15.11	Refit all collar seal cast iron wear seals hot end including seal gap setting and ensuring tensioning device operates correctly					X									
15.12	Remove four collar seal cast iron wear seals hot end				X										
15.13	Refit four collar seal cast iron wear seals hot end including seal gap setting and ensuring tensioning device operates correctly				X										
15.14	Close up collar seal housing hot end			X	X	X									
15.15	Remove rubbing ring hot end					X									
15.16	Refit rubbing ring hot end					X									
15.17	Re-align rubbing ring hot end														
15.18	Re-align collar seal housing run out to specification hot end														
15.19	Open all collar seal spring boxes cold end, inspect and report			X	X	X									
15.20	Refit new springs and stop washers on spring boxes cold end including checking for correct tensioning					X									
15.21	Close up spring boxes cold end			X	X	X									
15.22	Remove erosion protection on 1 spring box cold end			X											
15.23	Refit new erosion protection on 1 spring box cold end														
15.24	Remove erosion protection on 2 spring boxes cold end			X	X										
15.25	Refit new erosion protection on 2 spring boxes cold end			X	X										
15.26	Remove erosion protection on all spring boxes cold end					X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
15.27	Refit new erosion protection on all spring boxes cold end					X									
15.28	Remove all collar seal cast iron wear seals cold end					X									
15.29	Refit all collar seal cast iron wear seals cold end including seal gap setting and ensuring tensioning device operates correctly					X									
15.30	Remove four collar seal cast iron wear seals cold end				X										
15.31	Refit four collar seal cast iron wear seals cold end including seal gap setting and ensuring tensioning device operates correctly				X										
15.32	Close up collar seal housing cold end			X	X	X									
15.33	Remove rubbing ring cold end					X									
15.34	Refit rubbing ring cold end					X									
15.35	Realign rubbing ring cold end														
15.36	Re-align collar seal housing run out to specification cold end														
18	High Pressure Washing - Elements														
18.01	Carry out complete air heater water washing with high pressure system from the cold end of the air heater for a duration of 72 hours including all equipment required														
18.02	Carry out complete air heater water washing with high pressure system from the cold end of the air heater for a duration of 96 hours including all equipment required														
18.03	Carry out complete air heater water washing with high pressure system from the cold end of the air heater for a duration of 120 hours including all equipment required														
19	Drive System														
19.01	Remove drive motor					X									
19.02	Refit drive motor					X									
19.03	Remove coupling guard and inspect guard			X	X	X									
19.04	Clean coupling and inspect coupling			X	X	X									
19.05	Re-grease and close up coupling			X	X	X									
19.06	Carry out minor repairs to coupling guard and refit guard			X	X	X									
19.07	Remove motor coupling half														
19.08	Refit motor coupling half														
19.09	Remove gearbox coupling half														
19.10	Refit gearbox coupling half														

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
19.11	Remove gearbox labyrinth seal														
19.12	Refit gearbox labyrinth seal														
19.13	Remove gearbox oil and refill gearbox with new oil through filtration unit			X	X	X									
19.14	Remove the gearbox output shaft seal														
19.15	Refit the gearbox output shaft seal														
19.16	Align motor and gearbox														
19.17	Remove the complete gearbox and lower to gearbox to ground level					X									
19.18	Refit the complete gearbox including lifting the gearbox up to the air heater level from ground level					X									
19.19	Remove the felt seal on the bottom bearing cover plate														
19.20	Refit the felt seal on the bottom bearing cover plate														
19.21	Remove drive pinion				X	X									
19.22	Turn and refit drive pinion				X										
19.23	Refit drive pinion					X									
19.24	Align drive pinion height					X									
19.25	Align drive pinion penetration					X									
20	Pin Rack														
20.01	Remove complete pin rack					X									
20.02	Refit complete pin rack to correct alignment					X									
20.03	Turn over and refit complete pin rack to correct alignment														
20.04	Remove 1.0m erosion protection strips on pin rack stiffener pipes														
20.05	Refit 1.0m erosion protection strips on pin rack stiffener pipes														
20.06	Remove 4.0m erosion protection strips on pin rack stiffener pipes			X	X	X									
20.07	Refit 4.0m erosion protection strips on pin rack stiffener pipes			X	X	X									
20.08	Weld repair 2 off pin rack holding strips			X											
20.09	Weld repair 10 off pin rack holding strips				X	X									
20.10	Remove 2 off pin rack holding strips														
20.11	Refit 2 off pin rack holding strips														
20.12	Remove 10 off pin rack holding strips														
20.13	Refit 10 off pin rack holding strips														
20.14	Remove 2 meters of pin rack stiffener pipes			X											
20.15	Refit 2 meters of pin rack stiffener pipes including erosion protection			X											
20.16	Remove 10 meters of pin rack stiffener pipes				X	X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
20.17	Refit 10 meters of pin rack stiffener pipes including erosion protection				X	X									
21	Main Bearings - Grease														
21.01	Remove all grease pipes from lube tunnel and inspect for grease leaks					X									
21.02	Inspect grease piping for damage			X	X	X									
21.03	Clean out bearing compartment and all drip trays			X	X	X									
21.04	NDT inspect bearing support gussets				X	X									
21.05	Inspect hub and stator radial plate welds inside bearing compartment					X									
21.06	Thickness test hub plate hot end and cold end and report					X									
21.07	Open, clean and inspect guide bearing				X	X									
21.08	Open, clean and inspect support bearing				X	X									
21.09	Remove guide bearing					X									
21.10	Refit guide bearing and lubricate					X									
21.11	Remove support bearing					X									
21.12	Refit support bearing and lubricate					X									
21.13	Close guide bearing					X									
21.14	Close support bearing					X									
21.15	Close up bearing compartment			X	X	X									
22	Lubrication System - Grease System														
22.01	Remove and refit pump motor														
22.02	Remove and refit pump														
22.03	Remove and refit pressure regulating valve														
22.04	Remove and refit needle valve														
22.05	Fill grease tank			X	X	X									
22.06	Inspect lubrication pumps for leaks and repair leaks where required.			X	X	X									
22.07	Remove lubrication pumps and inspect couplings and bell housing/guards for damage. Repair any damage and replace coupling or bell housing if required. Refit pumps				X	X									
22.08	Send pumps away for overhaul					X									
22.09	Commission lubrication system by setting grease system			X	X	X									

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
23	Ducting Hot End														
23.01	Carry out window repairs of 1.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
23.02	Carry out window repairs of 5.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.			X											
23.03	Carry out window repairs of 10.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.				X	X									
23.04	Carry out window repairs of 1.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
23.05	Carry out window repairs of 5.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
23.06	Carry out window repairs of 10.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
23.07	Carry out window repairs of 1.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
23.08	Carry out window repairs of 5.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
23.09	Carry out window repairs of 10.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
24	Ducting Cold End														

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
24.01	Carry out window repairs of 1.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
24.02	Carry out window repairs of 5.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.			X											
24.03	Carry out window repairs of 10.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.				X	X									
24.04	Carry out window repairs of 1.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
24.05	Carry out window repairs of 5.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
24.06	Carry out window repairs of 10.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
24.07	Carry out window repairs of 1.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
24.08	Carry out window repairs of 5.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
24.09	Carry out window repairs of 10.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
25	Transition Ducting Hot End														
25.01	Carry out window repairs of 1.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
25.02	Carry out window repairs of 5.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.			X	X										
25.03	Carry out window repairs of 10.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.					X									
25.04	Carry out window repairs of 1.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
25.05	Carry out window repairs of 5.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
25.06	Carry out window repairs of 10.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
25.07	Carry out window repairs of 1.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
25.08	Carry out window repairs of 5.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
25.09	Carry out window repairs of 10.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
26	Transition Ducting Cold End														
26.01	Carry out window repairs of 1.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
26.02	Carry out window repairs of 5.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.			X	X										

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
26.03	Carry out window repairs of 10.0m in total of 6mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.					X									
26.04	Carry out window repairs of 1.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
26.05	Carry out window repairs of 5.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
26.06	Carry out window repairs of 10.0m in total of 8mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
26.07	Carry out window repairs of 1.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
26.08	Carry out window repairs of 5.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
26.09	Carry out window repairs of 10.0m in total of 10mm thick ducting plate by cutting out and re-welding with new material. Excluding removal of cladding and insulation if required.														
27	Walkways														
27.01	Carry out minor repairs on walkways			X	X										
27.02	Remove 1.0m ² of walkway grating				X										
27.03	Refit 1.0m ² of walkway grating				X										
27.04	Remove 4.0m ² of walkway grating					X									
27.05	Refit 4.0m ² of walkway grating					X									
27.06	Remove 1m of walkway grating support structure														
27.07	Refit 1m of walkway grating support structure														
27.08	Remove 4m of walkway grating support structure														
27.09	Refit 4m of walkway grating support structure														
27.10	Remove 10m of walkway grating support structure														
27.11	Refit 10m of walkway grating support structure														
28	Sootblower System - Rotary Valve														

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
28.01	Inspect the sootblower pipe for damage and erosion			X	X	X									
28.02	Inspect the sootblower pipe erosion protection plates			X	X	X									
28.03	Inspect sootblower rotary valve plunger, wear rings and labyrinth seal			X	X	X									
28.04	Inspect the sootblower piping for damage, erosion and holes complete from AH casing entry to sootblower device			X	X	X									
28.05	Inspect sootblower cross bellows for damage, erosion, holes and alignment			X	X	X									
28.06	Refurbish the sootblower pipe penetration system through the air duct walls					X									
28.07	Refurbish the sootblower actuating paddle mechanism			X	X	X									
28.08	Carry out correct setup and stroking for sootblower actuating paddle			X	X	X									
28.09	Remove one sootblower rotary valve			X	X										
28.10	Refit one sootblower rotary valve			X	X										
28.11	Remove all sootblower rotary valves					X									
28.12	Refit all sootblower rotary valves including new erosion protection					X									
28.13	Remove one sootblower header			X											
28.14	Refit one sootblower header			X											
28.15	Remove four sootblower headers				X										
28.16	Refit four sootblower headers				X										
28.17	Remove ten sootblower headers					X									
28.18	Refit ten sootblower headers					X									
28.19	Remove 1m of sootblower erosion protection plate			X											
28.20	Refit 1m of sootblower erosion protection plate			X											
28.21	Remove 5m of sootblower erosion protection plate				X										
28.22	Refit 5m of sootblower erosion protection plate				X										
28.23	Remove 10m of sootblower erosion protection plate					X									
28.24	Refit 10m of sootblower erosion protection plate					X									
28.25	Remove one sootblower cross compensator			X	X										
28.26	Refit one sootblower cross compensator including correct alignment			X	X										
28.27	Remove sootblower center compensator			X	X	X									
28.28	Inspect center compensator including sliding faces for damage and erosion			X	X	X									
28.29	Align sootblower center compensator correctly														
28.30	Refit sootblower center compensator			X	X	X									
29	Fire Protection System - Single Flow														

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
29.01	Remove 1 fire protection system spray nozzle only excluding piping			X											
29.02	Refit 1 fire protection system spray nozzle			X											
29.03	Remove 5 fire protection system spray nozzles only excluding piping				X	X									
29.04	Refit 5 fire protection system spray nozzles				X	X									
29.05	Remove 10 fire protection system spray nozzles only excluding piping														
29.06	Refit 10 fire protection system spray nozzles														
29.07	Remove 1m of fire protection system piping including erosion protection														
29.08	Refit 1m of fire protection system piping excluding erosion protection														
29.09	Remove 5m of fire protection system piping including erosion protection														
29.10	Refit 5m of fire protection system piping excluding erosion protection														
29.11	Remove 10m of fire protection system piping including erosion protection														
29.12	Refit 10m of fire protection system piping excluding erosion protection														
29.13	Remove 1m of fire protection system erosion protection			X											
29.14	Refit 1m of fire protection system erosion protection			X											
29.15	Remove 5m of fire protection system erosion protection				X										
29.16	Refit 5m of fire protection system erosion protection				X										
29.17	Remove 10m of fire protection system erosion protection					X									
29.18	Refit 10m of fire protection system erosion protection					X									
29.19	Remove fire protection system center manifold when center sootblower compensator is removed			X	X	X									
29.20	Inspect fire protection system center manifold internally			X	X	X									
29.21	Adjust and setup fire protection system center manifold control rods														
29.22	Refit fire protection system center manifold (Turn manifold if required)			X	X	X									
29.23	Remove 1 fire protection system compensator bellow														
29.24	Refit 1 fire protection system compensator bellow														

Matimba Power Station

Air Heater Scope Of Work

Unit 1-6

Item No	Description	Spares and Consumables Required	OP	IN	IR	GO	Dur/ Htr (Hrs)	Dur/ Unit (Hrs)	SE	A	W	S/S	L	Price/ Htr	Price/ Unit
29.25	Test fire protection system manually during air heater washing					X									
30	Commissioning														
30.01	Start lub system and test run air heater and ensure heaters run freely			X	X	X									
30.02	Engineering to witness, record and analyse online seal settings at first full load operation.			X	X	X									